

Making Everything Easier!™

Nikon® D7100™

FOR DUMMIES®

A Wiley Brand

Learn to:

- Adjust your camera's settings to capture any scene like a pro
- Master autofocus and autoexposure systems for improved images
- Shoot full HD video with your camera's video option

IN FULL COLOR!

Julie Adair King

*Author of Digital Photography
For Dummies*



Nikon® D7100™

FOR
DUMMIES®
A Wiley Brand

by Julie Adair King

FOR
DUMMIES®
A Wiley Brand

Nikon® D7100™ For Dummies®

Published by:

John Wiley & Sons, Inc.,
111 River Street,
Hoboken, NJ 07030-5774,
www.wiley.com

Copyright © 2013 by John Wiley & Sons, Inc., Hoboken,
New Jersey

Published simultaneously in Canada

No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, scanning or otherwise, except as permitted under Sections 107 or 108 of the 1976 United States Copyright Act, without the prior written permission of the Publisher. Requests to the Publisher for permission should be addressed to the Permissions Department, John Wiley & Sons, Inc., 111 River Street, Hoboken, NJ 07030, (201) 748-6011, fax (201) 748-6008, or online at <http://www.wiley.com/go/permissions>.

Trademarks: Wiley, For Dummies, the Dummies Man logo, Dummies.com, Making Everything Easier, and related trade dress are trademarks or registered trademarks of John Wiley & Sons, Inc. and may not be used without written permission. Nikon and D7100 are trademarks of Nikon Corporation. All other trademarks are the property of their respective owners. John Wiley & Sons, Inc. is not associated with any product or vendor mentioned in this book.

Limit of Liability/Disclaimer of Warranty: The publisher and the author make no representations or warranties with respect to the accuracy or completeness of the contents of this work and specifically disclaim all

warranties, including without limitation warranties of fitness for a particular purpose. No warranty may be created or extended by sales or promotional materials. The advice and strategies contained herein may not be suitable for every situation. This work is sold with the understanding that the publisher is not engaged in rendering legal, accounting, or other professional services. If professional assistance is required, the services of a competent professional person should be sought. Neither the publisher nor the author shall be liable for damages arising herefrom. The fact that an organization or Website is referred to in this work as a citation and/or a potential source of further information does not mean that the author or the publisher endorses the information the organization or Website may provide or recommendations it may make. Further, readers should be aware that Internet Websites listed in this work may have changed or disappeared between when this work was written and when it is read.

For general information on our other products and services, please contact our Customer Care Department within the U.S. at 877-762-2974, outside the U.S. at 317-572-3993, or fax 317-572-4002. For technical support, please visit www.wiley.com/techsupport.

Wiley publishes in a variety of print and electronic formats and by print-on-demand. Some material included with standard print versions of this book may not be included in e-books or in print-on-demand. If this book refers to media such as a CD or DVD that is not included in the version you purchased, you may download this material at <http://booksupport.wiley.com>. For more information about Wiley products, visit www.wiley.com.

Library of Congress Control Number: 2013937650

ISBN 978-1-118-53046-7 (pbk); ISBN 978-1-118-53040-5
(ebk); ISBN 978-1-118-53049-8 (ebk); ISBN 978-1-118-
53055-9 (ebk)

Manufactured in the United States of America

10 9 8 7 6 5 4 3 2 1

Nikon D7100 For Dummies®

Visit

www.dummies.com/cheatsheet/nikond7100 to view this book's cheat sheet.

Table of Contents

Introduction

[A Quick Look at What's Ahead](#)

[Icons and Other Stuff to Note](#)

[eCheat Sheet](#)

[Practice, Be Patient, and Have Fun!](#)

Part I: Fast Track to Super Snaps

Chapter 1: Getting the Lay of the Land

[Looking at Lenses](#)

[Choosing a lens](#)

[Attaching and removing lenses](#)

[Changing the focusing method \(auto or manual\)](#)

[Zooming in and out](#)

[Getting shake-free shots with Vibration Reduction \(VR\) lenses](#)

[Adjusting the Viewfinder Focus](#)

[Ordering from Camera Menus](#)

[Decoding the Displays](#)

[Working with Memory Cards](#)

[Using two cards at the same time](#)

[Formatting cards](#)

[Exploring External Camera Controls](#)

[Topside controls](#)

[Back-of-the-body controls](#)

[Front-left controls](#)

[Front-right controls](#)

[Hidden connections](#)

[Asking Your Camera for Help](#)

[Reviewing Basic Setup Options](#)

[Cruising the Setup menu](#)

[Browsing the Custom Setting menu](#)

[Choosing a storage folder](#)

[Restoring default settings](#)

[Chapter 2: Choosing Basic Picture Settings](#)

[Choosing an Exposure Mode](#)

[Choosing the Shutter-Release Mode](#)

[Single Frame and Quiet modes](#)

[Continuous \(burst mode\) shooting](#)

[Self-timer shooting](#)

[Mirror lockup \(MUP\)](#)

[Off-the-dial shutter release features](#)

[Choosing the Right Image Size and Image Quality Settings](#)

[Diagnosing quality problems](#)

[Considering image size: How many pixels are enough?](#)

[Understanding Image Quality options \(JPEG or Raw\)](#)

[JPEG: The imaging \(and web\) standard](#)

[Raw \(NEF\): The purist's choice](#)

[Reducing the Image Area \(DX versus 1.3x Crop\)](#)

[Chapter 3: Taking Great Pictures, Automatically](#)

[Setting Up for Automatic Success](#)

[As Easy as It Gets: Auto and Auto Flash Off](#)

[Taking Advantage of Scene Modes](#)

[Selecting a Scene mode](#)

[Checking out the Scene\(s\)](#)

[Chapter 4: Exploring Live View Photography and Movie Making](#)

[Using Your Monitor as a Viewfinder](#)

[Live View safety tips](#)

[Customizing the Live View display](#)

[Displaying the Live View preview on an HDMI screen](#)

[Exploring Live View Focusing](#)

[Choosing an Autofocus mode](#)

[Setting the AF-area mode](#)

[Stepping through the focusing process](#)

[Manual focusing in Live View mode](#)

[Shooting Still Pictures in Live View Mode](#)

[Shooting Movies](#)

[Easy-does-it movie recording](#)

[Adjusting basic recording settings](#)

[Screening Your Movies](#)

[Trimming Movies](#)

[Saving a Movie Frame as a Still Image](#)

[Part II: Working with Picture Files](#)

[Chapter 5: Playback Mode: Viewing, Erasing, and Protecting Photos](#)

[Customizing Basic Playback Options](#)

[Adjusting playback timing](#)

[Enabling automatic picture rotation](#)

[Viewing Images in Playback Mode](#)

[Viewing multiple images at a time](#)

[Displaying photos in Calendar view](#)

[Choosing which images to view](#)

[Magnifying photos during playback](#)

[Viewing Picture Data](#)

[Choosing data-display options](#)

[File Information mode](#)

[Highlights display mode](#)

[RGB Histogram mode](#)

[Shooting Data display mode](#)

[GPS Data mode](#)

[Overview mode](#)

[Deleting Photos](#)

[Deleting images one at a time](#)

[Deleting all photos](#)

[Deleting a batch of selected photos](#)

[Hiding Photos during Playback](#)

[Protecting Photos](#)

[Creating a Slide Show](#)

[Viewing Your Photos on a Television](#)

[Chapter 6: Downloading, Printing, and Sharing Your Photos](#)

[Choosing the Right Photo Software](#)

[Three free photo programs](#)

[Advanced photo programs](#)

[Sending Pictures to the Computer](#)

[Connecting the camera and computer](#)

[Starting the transfer process](#)

[Downloading using ViewNX 2](#)

[Processing Raw \(NEF\) Files](#)

[Processing Raw images in the camera](#)

[Processing Raw files in ViewNX 2](#)

[Planning for Perfect Prints](#)

[Check the pixel count before you print](#)

[Allow for different print proportions](#)

[Get print and monitor colors in sync](#)

[Preparing Pictures for Online Use](#)

[Prepping online photos using ViewNX 2](#)

[Creating screen-friendly copies in the camera](#)

[Copying Files from One Card to Another](#)

[Part III: Taking Creative Control](#)

[Chapter 7: Getting Creative with Exposure and Lighting](#)

[Introducing the Exposure Trio: Aperture, Shutter Speed, and ISO](#)

[Understanding exposure-setting side effects](#)

[Doing the exposure balancing act](#)

[Exploring the Advanced Exposure Modes](#)

[Reading \(And Adjusting\) the Meter](#)

[Setting Aperture, Shutter Speed, and ISO](#)

[Adjusting aperture and shutter speed](#)

[Controlling ISO](#)

[Choosing an Exposure Metering Mode](#)

[Sorting through Your Camera's Exposure-Correction Tools](#)

[Applying Exposure Compensation](#)

[Using Autoexposure Lock](#)

[Expanding tonal range with Active D-Lighting](#)

[Exploring high dynamic range \(HDR\) photography](#)

[Working with Flash](#)

[Setting the Flash mode](#)

[Adjusting flash output](#)

[Locking flash exposure on your subject](#)

[Exploring a few additional flash options](#)

[Bracketing Exposures](#)

[Bracketing exposure and flash](#)

[Bracketing Active D-Lighting](#)

[Chapter 8: Manipulating Focus and Color](#)

[Mastering the Autofocusing System](#)

[Choosing an Autofocus mode](#)

[Choosing an AF-area mode: One focus point or many?](#)

[Choosing the right autofocus combo](#)

[Selecting \(and locking\) an autofocus point](#)

[Autofocusing with still subjects: AF-S + Single Point](#)

[Focusing on moving subjects: AF-C + Dynamic Area](#)

[Exploring a few last autofocus tweaks](#)

[Focusing Manually](#)

[Manipulating Depth of Field](#)

[Controlling Color](#)

[Correcting colors with white balance](#)

[Changing the White Balance setting](#)

[Fine-tuning White Balance settings](#)

[Creating custom White Balance presets](#)

[Bracketing white balance](#)

[Choosing a Color Space: sRGB versus Adobe RGB](#)

[Taking a Quick Look at Picture Controls](#)

[Chapter 9: Putting It All Together](#)

[Recapping Basic Picture Settings](#)

[Shooting Still Portraits](#)

[Capturing Action](#)

[Capturing Scenic Vistas](#)

[Capturing Dynamic Close-Ups](#)

[Part IV: The Part of Tens](#)

[Chapter 10: Ten Fun \(And Practical\) Ways to Manipulate Your Photos](#)

[Applying the Retouch Menu Filters](#)

[Removing Red-Eye](#)

[Straightening Tilting Horizon Lines](#)

[Removing \(Or Creating\) Lens Distortion](#)

[Correcting Perspective](#)

[Cropping \(Trimming\) Your Photo](#)

[Manipulating Exposure and Color](#)

[Creating Monochrome Images](#)

[Playing with Special Effects](#)

[Retouch menu special-effects filters](#)

[Shooting in Effects mode](#)

[Two Roads to a Multi-Image Exposure](#)

[Chapter 11: Ten More Ways to Customize Your Camera](#)

[Creating Custom Exposure Modes](#)

[Creating Your Own Menu](#)

[Adding Image Comments](#)

[Embedding a Copyright Notice](#)

[Customizing File and Folder Names](#)

[Changing the Purpose of the OK Button](#)

[Customizing the Command Dials](#)

[Customizing the Fn, Depth-of-Field Preview, and AE-L/AF-L Buttons](#)

[Customizing buttons for still photography](#)

[Customizing buttons for movie recording](#)

[Modifying the Role of the Shutter Button](#)

[About the Author](#)
[Cheat Sheet](#)

Introduction

Nikon. The name has been associated with top-flight photography equipment for generations. And the introduction of the D7100 has only enriched Nikon's well-deserved reputation, offering all the control a die-hard photography enthusiast could want while at the same time providing easy-to-use, point-and-shoot features for the beginner.

In fact, the D7100 offers so *many* features that sorting them all out can be more than a little confusing, especially if you're new to digital photography, SLR photography, or both. For starters, you may not even be sure what SLR means or how it affects your picture-taking, let alone have a clue as to all the other techie terms you encounter in your camera manual — *resolution, aperture, white balance*, and so on. And if you're like many people, you may be so overwhelmed by all the controls on your camera that you haven't yet ventured beyond fully automatic picture-taking mode. Which is a shame because it's sort of like buying a Porsche and never actually taking it on the road.

Therein lies the point of *Nikon D7100 For Dummies*. Through this book, you can discover not just what each bell and whistle on your camera does, but also when, where, why, and how to put it to best use. Unlike many photography books, this one doesn't require any previous knowledge of photography or digital imaging to make sense of things, either. In classic *For Dummies* style, everything is explained in easy-to-understand language, with lots of illustrations to help clear up any confusion.

In short, what you have in your hands is the paperback version of an in-depth photography workshop tailored specifically to your Nikon picture-taking powerhouse.

A Quick Look at What's Ahead

This book is organized into four parts, each devoted to a different aspect of using your camera. Although chapters flow in a sequence that's designed to take you from absolute beginner to experienced user, I've also tried to make each chapter as self-standing as possible so that you can explore the topics that interest you in any order you please.

Here's a brief preview of what you can find in each part of the book:

- ✓ **Part I: Fast Track to Super Snaps:** Part I contains four chapters to help you get up and running. [Chapter 1](#) offers a tour of the external controls on your camera, shows you how to navigate camera menus, and walks you through initial camera setup. [Chapter 2](#) explains basic picture-taking options, such as shutter-release mode and Image Quality settings, and [Chapter 3](#) shows you how to use the camera's fully automatic exposure modes. [Chapter 4](#) explains the ins and outs of using Live View, the feature that lets you compose pictures on the monitor, and also covers movie recording.
- ✓ **Part II: Working with Picture Files:** This part offers two chapters dedicated to after-the-shot topics. [Chapter 5](#) explains how to review your pictures on the camera monitor, delete unwanted images, and protect your favorites from accidental erasure. [Chapter 6](#)

offers a look at some photo software options — including Nikon ViewNX 2, which ships free with your camera — and guides you through the process of downloading pictures to your computer and preparing them for printing and online sharing.

- ✓ **Part III: Taking Creative Control:** Chapters in this part help you unleash the full power of your camera by moving into the advanced shooting modes (P, S, A, and M). [Chapter 7](#) covers the critical topic of exposure, and [Chapter 8](#) explains how to manipulate focus and color. [Chapter 9](#) summarizes all the techniques explained in earlier chapters, providing a quick-reference guide to the camera settings and shooting strategies that produce the best results for portraits, action shots, landscape scenes, and close-ups.
- ✓ **Part IV: The Part of Tens:** In famous *For Dummies* tradition, the book concludes with two “top ten” lists containing additional bits of information and advice. [Chapter 10](#) covers the photo-editing and effects tools found on the camera’s Retouch menu and also shows you how to use the Effects exposure mode to add special effects to movies and photos as you record them. [Chapter 11](#) wraps up the book by detailing some camera customization features that, although not found on most “Top Ten Reasons I Bought My Nikon D7100” lists, are nonetheless interesting, useful on occasion, or a bit of both.

Icons and Other Stuff to Note

If this isn’t your first *For Dummies* book, you may be familiar with the large, round icons that decorate its margins. If not, here’s your very own icon-decoder ring:



A Tip icon flags information that will save you time, effort, money, or some other valuable resource, including your sanity. Tips also point out techniques that help you get the best results from specific camera features.



When you see this icon, look alive. It indicates a potential danger zone that can result in much wailing and teeth-gnashing if ignored. In other words, this is stuff that you really don't want to learn the hard way.



Lots of information in this book is of a technical nature — digital photography is a technical animal, after all. But if I present a detail that is useful mainly for impressing your technology-geek friends, I mark it with this icon.



I apply this icon either to introduce information that is especially worth storing in your brain's long-term memory or to remind you of a fact that may have been displaced from that memory by some other pressing fact.

Additionally, I need to point out these extra details that will help you use this book:

✓ **Other margin art:** Replicas of some of your camera's buttons and onscreen symbols also appear in the margins next to some paragraphs. I include these to provide a quick reminder of the appearance of the button or feature being discussed.

- ✓ **Software menu commands:** In sections that cover software, a series of words connected by an arrow indicates commands that you choose from the program menus. For example, if a step tells you to “Choose File⇒Convert Files,” click the File menu to unfurl it and then click the Convert Files command on the menu.
- ✓ **Online updates:** Occasionally, Wiley's technology books are updated. If this book has technical updates, they'll be posted at www.dummies.com/go/nikond7100updates.

eCheat Sheet

As a little added bonus, you can find an electronic version of the famous *For Dummies* eCheat Sheet at www.dummies.com/cheatsheet/nikond7100. The eCheat Sheet contains a quick-reference guide to all the buttons, dials, switches, and exposure modes on your camera. Print it out, and tuck it in your camera bag for times when you don't want to carry this book with you.

Practice, Be Patient, and Have Fun!

To wrap up this preamble, I want to stress that if you initially think that digital photography is too confusing or too technical for you, you're in very good company.

Everyone finds this stuff a little mind-boggling at first. So take it slowly, experimenting with just one or two new camera settings or techniques at first. Then, each time you go on a photo outing, make it a point to add one or two more shooting skills to your repertoire.

I know that it's hard to believe when you're just starting out, but it really won't be long before everything starts

to come together. With some time, patience, and practice, you'll soon wield your camera like a pro, dialing in the necessary settings to capture your creative vision almost instinctively.

So without further ado, I invite you to grab your camera, a cup of whatever it is you prefer to sip while you read, and start exploring the rest of this book. Your D7100 is the perfect partner for your photographic journey, and I thank you for allowing me, through this book, to serve as your tour guide.

Part I

Fast Track to Super Snaps



Visit www.dummies.com for more great *For Dummies* content online.

In this part . . .

- ✓ Get familiar with the basics of using your camera, from attaching lenses to using the Information display and Control panel.
- ✓ Find out how to select the shutter-release mode, exposure mode, picture resolution, file type (JPEG or Raw), and image area.
- ✓ Discover tips for getting good results in the automatic exposure modes.
- ✓ Start taking creative control by stepping up to Scene modes.
- ✓ Switch to Live View mode to compose pictures by using the monitor.
- ✓ Record, play, and trim digital movies.



1

Getting the Lay of the Land

In This Chapter

- ▶ Attaching and using an SLR lens
 - ▶ Adjusting the viewfinder to your eyesight
 - ▶ Selecting from menus
 - ▶ Figuring out the displays
 - ▶ Working with memory cards
 - ▶ Getting acquainted with your camera
 - ▶ Customizing basic operations
-

If you're like me, shooting for the first time with a camera as sophisticated as the Nikon D7100 produces a blend of excitement and anxiety. On one hand, you can't wait to start using your new equipment, but on the other, you're a little intimidated by all its buttons, dials, and menu options.

Well, fear not: This chapter provides the information you need to start getting comfortable with your D7100. Along with an introduction to the camera's external controls, I offer details about working with lenses and memory cards, viewing and adjusting camera settings, and choosing basic camera setup options.

Looking at Lenses

One of the biggest differences between a digital point-and-shoot camera and a dSLR (*digital single-lens reflex*) camera is the lens. With a dSLR, you can change lenses to suit different photographic needs, going from an extreme close-up lens to a super-long telephoto, for example. In addition, a dSLR lens has a focusing ring that gives you the option of focusing manually instead of relying on the camera's autofocus mechanism.

I don't have room in this book to go into detail about the science of lenses, nor do I think that an in-depth knowledge of the subject is terribly important to your photographic success. But the next few sections offer advice that may help when you're shopping for lenses, figuring out whether the lenses you inherited from Uncle Ted or found on eBay will work with your D7100, and taking the steps involved in actually mounting and using a lens.

Choosing a lens

To decide which lens is the best partner for your camera, start by considering these factors:

- ✓ **Lens compatibility:** You can mount a wide range of lenses on your D7100, but some lenses aren't fully compatible with all camera features. For example, with some lenses, you can't take advantage of autofocus and must focus manually.

Your camera manual lists all the lens types that can be mounted on the camera and explains what features are supported with each type. For maximum compatibility, look for these types: Type D or G AF Nikkor, AF-S Nikkor, or AF-I Nikkor. (The latter is an

older, expensive professional lens that is no longer sold but might be available on the resale market.)

All the aforementioned lens types (as well as some others) offer CPU (central processing unit) technology, which allows the lens to talk to the camera. This feature is critical to getting maximum performance from the autofocus system, exposure metering system, and so on. That's not to say that you can't use a non-CPU lens; you just lose access to some camera features.

Information in this book assumes that you're using a CPU lens that supports all the camera's functions. If your lens doesn't meet that criteria, check the camera manual for specifics on what features are unavailable or need to be implemented differently.

✓ **Focal length and the crop factor:** The focal length of a lens, stated in millimeters, determines the angle of view that the camera can capture and the spatial relationship of objects in the frame. Focal length also affects *depth of field*, or the distance over which focus appears acceptably sharp.

You can loosely categorize lenses by focal length as follows:

- *Wide-angle:* Lenses with short focal lengths — generally, anything under 35mm — are known as *wide-angle lenses*. A wide-angle lens has the visual effect of pushing the subject away from you and making it appear smaller. As a result, you can fit more of the scene into the frame without moving back. Additionally, a wide-angle lens has a large depth of field, which means that both the subject and background objects appear sharp. These characteristics make wide-angle lenses ideal for landscape photography.

- *Telephoto*: Lenses with focal lengths longer than about 70mm are *telephoto* lenses. These lenses create the illusion of bringing the subject closer to you, increase the subject's size in the frame, and produce a short depth of field so that the subject is sharply focused but distant objects are blurry. Telephoto lenses are great for capturing wildlife and other subjects that don't permit up-close shooting.
- *Normal*: A focal length in the neighborhood of 35mm to 70mm is considered "normal" — that is, somewhere between a wide-angle and telephoto. This focal length produces the angle of view and depth of field that are appropriate for the kinds of snapshots that most people take.

[Figure 1-1](#) offers an illustration of the difference that focal length makes, showing the same scene captured at 42mm (left image) and 112mm (right image). Of course, the illustration shows just two of countless possibilities, and the question of which focal length best captures a scene depends on your creative goals.



Figure 1-1: I used a focal length of 42mm to capture the first image and then zoomed to a focal length of 112mm to capture the second one.



Note, however, that the focal lengths stated here and elsewhere in the book are so-called *35mm*

equivalent focal lengths. Here's the deal: For reasons that aren't really important, when you put a standard lens on most digital cameras, including your D7100, the available frame area is reduced, as if you took a picture on a camera that uses 35mm film negatives and then cropped it.

This so-called *crop factor* varies depending on the camera, which is why the photo industry adopted the 35mm-equivalent measuring stick as a standard. With the D7100, the crop factor is 1.5. So the 18–105mm kit lens, for example, captures the approximate area you would get from a 27–158mm lens on a 35mm film camera. (Multiply the crop factor by the lens focal length to get the actual angle of view.) In [Figure 1-2](#), the red line indicates the image area that results from the 1.5 crop factor compared with the shot you would get from the same focal length lens mounted on a 35mm film camera.

When shopping for a lens, it's important to remember this crop factor to make sure that you get the focal length designed for the type of pictures you want to take.



Figure 1-2: The 1.5 crop factor produces the angle of view indicated by the red outline.



Not sure which focal length to choose? Here's a really cool online tool to help you understand the subject more: Point your web browser to <http://imaging.nikon.com>, click the link for Nikkor lenses, and then click the link for the Nikkor Lenses Simulator. Using this interactive tool, you can see exactly how different lenses capture the same scene.

✓ **Prime versus zoom lenses:** A *prime* lens is a single focal-length lens. With a zoom lens, you get a range of focal lengths in one unit. For example, the kit lens I feature in this book has a focal-length range of 18–105mm.

Why select a lens that offers a single focal length when a zoom lens offers a range of focal lengths? In a

word, quality. Because of some lens science I won't bore you with, you typically see some reduction in picture quality at certain points in the range of a zoom lens. On the flip side, a zoom lens is certainly more convenient than carting around a bag of prime lenses with different focal lengths. And you can get exceptional image quality from many zoom lenses, even with some *super zooms*, which offer a huge range of focal lengths.

✓ **Aperture range:** The *aperture* is an adjustable diaphragm in a lens. By adjusting the aperture size, you control the amount of light that enters through the lens and strikes the image sensor, thereby controlling exposure. The aperture setting also affects depth of field: A wide-open aperture produces a short depth of field, so the subject is sharply focused, but distant objects appear blurry; a narrow aperture produces a long depth of field so that both the subject and distant objects appear sharp.

Chapters [7](#) and [8](#) cover these issues in detail. For the purposes of lens shopping, you need to know just a few things.

- *Every lens has a specific range of aperture settings.* Obviously, the larger that range, the more control you have over exposure and depth of field.
- *The larger the maximum aperture, the “faster” the lens.* Aperture settings are stated in *f-stops*, with a lower number meaning a larger aperture. For example, a setting of $f/2$ results in a more open aperture than $f/4$. And if you have one lens with a maximum aperture of $f/2$ and another with a maximum aperture of $f/4$, the $f/2$ lens is said to be *faster* because you can open the aperture wider, thereby allowing more light into the camera and

permitting the image to be captured in less time. This not only benefits you in low-light situations but also when photographing action, which requires a fast shutter speed (short exposure time). So, all other things being equal, a faster lens is better.

- *With some zoom lenses, the maximum and minimum aperture change as you zoom the lens.* For example, when you zoom to a telephoto focal length, the maximum aperture generally gets smaller — that is, you can't open the aperture as much as you can at a wide-angle setting. You can buy lenses that maintain the same maximum and minimum aperture throughout the whole zoom lens, but you pay more for this feature.

After studying these issues and narrowing down your choices, finding the right lens in the category you want is just a matter of doing some homework. Study lens reviews in photography magazines and online photography sites to find the best performing lens in your price range.

Attaching and removing lenses

Whatever lens you choose, follow these steps to attach it to the camera body:

- 1. Turn off the camera.**
- 2. Remove the cap that covers the lens mount on the front of the camera.**
- 3. Remove the cap that covers the back of the lens.**
- 4. Hold the lens in front of the camera so that the mounting index on the lens aligns with the one on the camera.**

The *mounting index* is a marker found on both the lens and the camera body to indicate how to align the two